




QUICK 2020D+ REWORK STATION

Instruction Manual



Thank you for purchasing our products. Please keep the instruction manual properly for future reference.

Contents

1. Safety Instructions.....	1
2. Overview.....	2
3. Product Characteristics.....	2
4. Product Specifications.....	3
5. Functional Descriptions.....	3
5.1. Dimensions.....	3
5.2. Part Descriptions.....	4
5.3. Key Descriptions.....	4
5.4. Function Descriptions of the Main Interface.....	5
6. Installation and Connection.....	6
6.1. Installation of Rework Station.....	6
6.2. Connection of Main Unit.....	6
7. Operation.....	7
8. Password Settings.....	7
9. Parameter Settings.....	8
10. New Passwords Settings.....	9
11. Temperature Calibration.....	9
12. Replacing the Heater.....	10
12.1. Steps of Removing the Heater.....	10
12.2. Steps of Replacing the Heater.....	11
13. Installing and Removing the Nozzle.....	11
14. Troubleshooting.....	12

1.Safety Instructions



CAUTION

- During the installation and use of this product, all electrical safety regulations of the country and regions must be strictly observed.
- The power supply must be disconnected when disassembling the product. Do not operate with power on.
- If the product does not work properly, please contact the supplier or our company, and do not disassemble or change the product in any way. We are not responsible for any problems caused by unauthorized maintenance or modification.



WARNING

- Don't install the product in a place where the surface is easy to shake or be impacted, as it may damage the product.
- Don't place the product in places where it may be exposed to rain or moisture.
- The product should be used away from places where there is magnetic interference.
- Don't use in flammable and explosive environments.
- Pay attention to the air outlet and its surroundings. High temperature operation, be careful of burns.
- Power supply should be turned off during breaks or after work to avoid safety accidents.
- Please keep the air outlet unblocked and ensure there is no obstruction.
- Check and maintain the product regularly. Do not use the product when it is damaged, especially when the power cord is damaged.
- The handle must be correctly placed on the holder, and do not replace it on the work surface.After completion,turn off the power switch when the machine automatically cools down to below 100°C (Enter Sleeping state).
- When the machine is not used for a long time, please unplug the power cord.

2.Overview

This product is used to rework various components, such as SMD, SOP, SOG, etc. It can be used in different applications, such as heat shrinkage, drying, paint removal, adhesive removal, thawing, preheating, disinfection, etc. Adjustable air volume, suitable for small air volume and large air volume heating occasions.

3.Product Characteristics


- Closed loop sensor, temperature can be controlled by zero voltage triggering mode and adjusted conveniently, accurate and stable, large power, rapid heating.
- Stepless adjustable airflow, with a large range; digital temperature display, easy temperature adjustment, suitable for various occasions.
- Equipped with a sensitive magnetic control sensor. Pick up the handle, the system enters the working mode; put the handle back to the holder, the system enters the standby state.
- Compact body, occupy small space.

4.Product Specifications

Product model	2020D+
Display	LCD
Power	750W
Working voltage	AC 110V/220V
Temperature range	100~500°C
Airflow range	1~100 Class
Max airflow	30L/min
Dimensions(L*W*H)	170*151*98mm
Weight	About 1.5 Kg


5.Functional Descriptions

5.1.Dimensions



Unit: mm


5.2.Part Descriptions




5.3.Key Descriptions

Button	Function Descriptions
<ul style="list-style-type: none"> • •• ••• 	<ol style="list-style-type: none"> 1. Press to select channel 1 to channel 3. 2. Long press •, ••, or ••• to save the airflow and temperature values of the current channel.
<p>▲/▼</p>	<ol style="list-style-type: none"> 1. Adjust the temperature 2. Press at the same time to enter the temperature calibration mode.

5.4.Function Descriptions of the Main Interface



Symbols	Descriptions
	Air volume
CHO	Temporary channel
COOL	Cooling state

6.Installation and Connection

6.1.Installation of Rework Station

When the station is used for the first time, the hot air holder must be installed, as shown in the figure below.

- 1) Remove the two screws on the left side of the machine that fixed the holder.
- 2) Align the mounting hole of the hot air desoldering holder with the two screw holes on the machine, and tighten the two screws that are removed.
- 3) Install the hot air desoldering holder, place the handle on the holder, and check whether it is suitable.

Note: The hot air handle holder can be installed on the left or right side of the system according to actual needs.



6.2.Connection of Main Unit

Connect the power supply to the station, turn on it and start working.


7.Operation

Airflow Adjust the air knob clockwise to increase the airflow, otherwise decrease the air volume. Adjust the air knob in a wide range to quickly increase or decrease the airflow.

Temperature Press " ▲ " or " ▼ ": temperature increases or decreases by 1 °C. Long press " ▲ " or " ▼ ": temperature increases or decreases rapidly.

Channel Press •, ••, or ••• to select channels 1~3. Long press •~••• to save the airflow and temperature values of the current channel.

Sleeping Put the handle on the handle holder, and the system will automatically enter the large air volume cooling state; when the temperature drops to 100 °C, the system will immediately enter the sleeping state.



8.Password Settings

The initial password is "000", and in this state, you can set the temperature. If you need to limit the temperature adjustment, you must change the password.

Enter password setting mode


- 1) Turn off the station, press the " ▲ " and " ▼ " keys at the same time, and then turn on the station.
- 2) Long press the " ▲ " and " ▼ " keys, "C" will be displayed after a beep sound, and the "---" display on the interface.
- 3) After input the correct password, go to parameter setting.

Input the initial password

- 1) The screen shows "- -" and the hundreds digit flashes, at this time the digit can be adjusted (enter the initial password).
- 2) Input the original password: adjust the air knob to change the hundreds digit number, press the "▲" key to select the digit, when the tens digit starts to flash, it can be set. The setting method of the tens digit and one digit are the same as the hundreds digit. When the one digit setting is completed, press and hold the "▲" and "▼" keys at the same time to confirm the setting.
- 3) **If the first password is wrong:** directly enter the second password input mode, and the password input way is the same as the first time. (There are two chances of password input.)
- 4) **If the password entered twice is wrong:** the screen display "ERR", and directly to the main interface.
- 5) **If the first or second password is correct:** go directly to parameter setting and the screen display "-1-".

9.Parameter Settings

- 1) If password is input correctly, the parameter menu can be entered, as shown in the following figure



- 2) Press the "▲" or "▼" key, after selecting the -1-parameter menu, press the "▲" and "▼" keys at the same time to return to the main interface; after selecting the parameter menu -2-, press the "▲" and "▼" keys at the same time to enter the new password setting.

10. New Passwords Settings

1) After entering the new password setting, the screen shows "---" and the hundreds digit blinks.

2) Adjust the air knob to change the hundreds digit, press the "▲" button to move the digit, when the tens digit starts blinking, it can be set. The setting method of the tens and one digit is the same as that of the hundreds digit. When the one digit setting is completed, press and hold the "▲" and "▼" keys at the same time to confirm. Enter the second password input mode, and the password input way is the same as the first time.

Note: If the two passwords input are not the same, the screen will display "ERR", indicating that the password setting is unsuccessful. It will return to the parameter setting, and the password will remain unchanged.

If two passwords input are the same, the screen displays "OK", indicating that the password setting is successful, and it returns to the parameter setting. Shut down and restart the machine, the new password takes effect.

11. Temperature Calibration

1) Set the machine temperature to 300°C. Use QUICK196 to test the temperature of the air outlet and write down the readings.

2) Press and hold the "▲" and "▼" keys at the same time for about 2 seconds, the display will show "CAL" and enter the temperature calibration interface.


3) Press "▲" or "▼" to adjust the temperature to the measured value.

4) Long press the "▲" and "▼" keys at the same time for about 2 seconds, and return to the main interface with a beep. It indicates the temperature calibration is successful.




Note: If there is no QUICK196, it is recommended that the temperature measuring head of the external sensor of the thermometer be placed 3~5mm away from the nozzle for temperature test.

12.Replacing the Heater




12.1.Steps of Removing the Heater

- 1) Unscrew the handle at the end of the two ⑥ Screws;
- 2) Turn down the ① Heat resistant bushing at the front of the handle counterclockwise and remove the ⑤ Handle upper shell;
- 3) Take out the ⑦ Fan, and unscrew the three ⑨ Screws fixing the circuit board;
- 4) Remove the two white wires of the ④ Heater and the red and blue wires of the sensor with a soldering iron.
- 5) Remove the 858 mica ring, and take the ④ Heater out of the ② Steel pipe.

 Note: All operating steps are performed with the power disconnected and the handle cooled.

12.2.Steps of Replacing the Heater

- 1) Install ④ Heater into the ② Steel pipe. Solder the new heater and sensor wires into the hole according to the hole position of the removal, cut off the excess wire, and pay attention to the correct position of red and blue wires.
- 2) Align the circuit board against the hole in the ⑧ Handle lower shell and fix it with three ⑨ Screws
- 3) Put the ⑦ Fan in a good position. Align the convex points of ⑤⑧ the upper and lower shells of the handle with the steel pipe holes, and close them. Then tighten ①Heat resistant bushing
- 4) Tighten the two ⑥ Screws at the end of the handle
- 5) After replacing the heater, please do the following measurements:




- 6) Calibrate the temperature, refer to temperature calibration.

⚠️ Note: Do not burn the wiring when you replace the heater, and do not solder the wiring for too long time.

13.Installing and Removing the Nozzle

- 1) Place the selected nozzle inside the steel pipe of the air outlet of the handle, and the four positioning catches on the nozzle must enter the installing slot of the steel pipe.
- 2) Stuck the nozzle with the wrench provided and turn it clockwise. The two fixing points of the wrench are placed in the two slots of the nozzle.

3) To remove the nozzle, just use a wrench to stuck the nozzle and turn it counterclockwise until it is loosed, then take out the nozzle.



14.Troubleshooting

No.	Error	Fault Descriptions
1	H-E	Indicates that there is a problem with the heater and the heater needs to be checked or replaced.
2	S-E	Indicates that there is a problem with the sensor and the sensor needs to be checked or replaced.
3	F-E	Indicates that the fan is faulty and needs to be checked or replaced.

Warranty Card

●The warranty period of this product is calculated from the date of Purchase. During the warranty period, if the product breaks down during normal use, show the original warranty card and enjoy free service in the authorized repair company(or our company).

Please keep the purchase certificate and this warranty card and show it before maintenance.

●During the warranty period, the following repairs need to be paid:

- a.Unable to offer valid warranty card or certificate;
- b.The purchase date, sales company and other items are not completely filled or the warranty card is altered;
- c.Damage caused by failure to follow the use methods and precautions in the manual;
- d.Damage caused by disassembly, repair and modification of products without authorization of the manufacturer;
- e.Replacement of vulnerable and consumable parts.

●All items of the warranty card shall be completely filled in by the agent or user to obtain a 12-month warranty period.

●Please keep this warranty card properly It will not be re-offered after.

QUICK INTELLIGENT EQUIPMENT
CO., LTD.

ADD: NO.11, FengXiang Road, Wujin
High-Tech Industrial Development
Zone, Jiangsu, China

TEL: 86-519-86225678

FAX: 86-519-86558599

POSTCODE: 213167

WEBSITE: www.quick-global.com

Warranty Card

Type: _____

Model No.: _____

Serial No.: _____

Delivery Date: _____

Warranty File Card

Type: _____

Model No.: _____

Serial No.: _____

Delivery Date: _____

Address : _____

Postcode: _____

Telephone: _____

Contact Person: _____

QUICK INTELLIGENT EQUIPMENT CO., LTD.

ADD: NO.11, FengXiang Road, Wujin
High-Tech Industrial Development Zone,
Jiangsu, China

TEL: 86-519-86225678

FAX: 86-519-86558599

POSTCODE: 213167

WEBSITE: www.quick-global.com

